

REDFYRE FREESTANDING COOKER

YOUR TECHNICAL QUESTIONS ANSWERED

What types of fuel can be used to run the Freestanding Cooker?
It can be run on Natural Gas or LPG.

What style of flue can be used with this model?

No flue is required thus ensuring that the cooker is suitable in most locations such as against an internal wall or in an island/peninsula arrangement. Also should you wish to move the cooker, it can be easily relocated.

Will the floor need reinforcing?

As long as the floor is not suspended there should be no reason to reinforce. However your Redfyre dealer will confirm this when undertaking a site survey.

Does the cooker require an extractor fan?

We would recommend that an extractor is fitted but it is not a prerequisite. The Freestanding Cooker should, however, be situated in a room with ample ventilation. Your dealer will be able to advise you further.

Can the Freestanding Cooker supply domestic hot water?

No, the Freestanding is a cooker only model.

Is the Freestanding Cooker designed for intermittent use?

Yes, the Freestanding Cooker has been designed to be flexible to meet the demands of modern life. There is a built in seven day timer which allows the cooker to be programmed up to three times a day to switch on when required, thus ensuring it is up to cooking temperature when required.

How often should my Freestanding Cooker be serviced?

The Freestanding Cooker requires servicing once a year.

N.B. Please note it is imperative that your dealer performs a site survey prior to installation. Failure to do so will almost certainly result in impaired long-term performance.

